

MAGNOLIA



OWNERS MANUAL

20-24 Hepburn Road, Doncaster Victoria, Australia 3108

magnoliad on caster hill.com. au



Welcome to your Apartment

Congratulations on your purchase and becoming a valued customer of Stanleyfield Pty Ltd

Looking after your apartment

It is very important that you maintain your apartment as to ensure the longevity of its finishes and fixtures. Consult your Owner's Manual and Owner's Pack for care and maintenance instructions – ensure experienced and licensed tradespeople are engaged to carry out repairs and maintenance works.

The Owner's Manual provides useful information about your new apartment. It is a guide to moving-in, establishing your service accounts, understanding the **Owners Corporation** and caring for your apartment.

The Owner's Pack includes essential items such as your keys, manufacturer's instructions, operating manuals and warranty cards for your appliances.

Table of Contents

About	this ma	anual	3
Impor	tant con	ntacts	3
1	Movin	ng-in guide	4
	1.1	Moving-in procedures and protection measures	
	1.2	For your action: Service connections	
	1.3	For your information	5
2	Being in an Owners Corporation		
	2.1	Strata title	7
	2.2	Owners Corporation	7
	2.3	Strata Managing Agent	7
	2.4	Levies: Administration and sinking fund	8
	2.5	Strata by-laws	8
	2.6	Modifications to your apartment	8
	2.7	Acoustic and fire separation between apartments	9
	2.8	Safety: Cleaning and maintenance protocol	10
3	Comn	mon facilities	11
	3.1	Resident entry and security	11
	3.2	Visitor access	11
	3.3	Mail	12
	3.4	Garbage and recycling	
	3.5	Fire procedures and safety	12
4	Aparti	ment services	14
	4.1	Electrical service	14
	4.2	Gas service	14
	4.3	Water service	15
	4.4	Hot water	15
	4.5	Air conditioning	15
	4.6	Telephone and fax	16
	4.7	Telephone lines	16
	4.8	Free to air TV	17
	4.9	Pay TV (cable)	17
	4.10	Intercom	17
	4.11	Smoke detection	17
	4.12	Door and window security	18
	4.13	Car Stacking Equipment	18

5	Gene	ral maintenance	19
	5.1	Finishes schedule and sub-contractor and suppliers list	19
	5.2	Appliances	19
	5.3	Paint	19
	5.4	Timber Flooring	20
	5.5	Lighting	20
	5.6	Aluminium doors and windows	20
	5.7	Door and window hardware	21
	5.8	Glass windows and balustrades, shower screens, splashbacks, vanity and robe mirrors	21
	5.9	Tapware	22
	5.10	Stone benchtops	22
	5.11	Tiles floor, walls – porcelain or vitrified	23
	5.12	Stainless steel kitchen sink, trims etc.	23
	5.13	Cupboard joinery	23
	5.14	Sanitary-ware acrylics, porcelains	24
	5.15	Ceiling exhaust ventilation grill	24
	5.16	Laundry floor waste	24
	5.17	External tiles	25
6	Enviro	onmentally Friendly Tips	26
	6.1	Living rooms	26
	6.2	Lighting	26
	6.3	Kitchen	26
	6.4	Bathroom	27
	6.5	Laundry	27
	6.6	Waste	27
Apper	ıdix A:	Copy of the by-laws	28
Apper	ıdix B:	Subcontractors/Services Contacts	29
Apper	ıdix C:	Finishes schedule/Supplier Contacts	30
Anner	idix D:	Attachments	32

Attachments included in Appendix D:

- -Condensation in Apartments Information Sheet
- -Security System Operational Instructions
- -Smoke Alarm Instruction Manual
- -Intercom Operational Instructions
- -Air conditioner Unit Operational Instructions
- -Range hood User Manual
- -Oven User Manual
- -Dishwasher User Manual
- -Cooktop User Manual
- -Fridge User Manual
- -Timber Flooring Maintenance Information
- -NBN Connection Information
- -Benchtop Care/Maintenance Information
- -Paint Care/Maintenance Instructions
- -Carpet Care/Maintenance Instructions
- -Waste Chute Training and Operation Manual

About this manual



An icon like this indicates important information.



An icon like this refers you to additional documentation included in your Owners Pack.

Important contacts

Building Management



Keep your Owners Corporation & Building Manager details readily available

Owners Corporation

Cura Community Management

Phone: 0411 880 876

Contact Person: Patrick Jiang

Building Manager

Brian Reed

Phone: 0401 097 858

Email: <u>brian@curastrata.com.au</u>

1 Moving-in guide

1.1 Moving-in procedures and protection measures

All residents are required to follow moving-in procedures, to ensure adequate access to building and loading facilities, protection of common property and minimal disruption to residents.

Residents must contact the Building Manager prior to moving in as to arrange access and confirm move in procedures.

Procedures may involve:

- Booking a suitable moving-in time: to ensure loading facilities are available, adequate protection measures
 are installed in the lift and common property, and residents are not disturbed;
- Providing a refundable deposit: to cover damage to common property;
- Insurance: to ensure your removalist company has suitable insurance to cover damage to common property; and
- Rubbish removal: To ensure suitable disposal by Owners.

The following are recommended measures for protecting the building and your apartment while moving-in:

- Ceilings, Walls and Doors: Use common sense as to avoid scuffing or chipping ceilings, walls and door frames. Pay particular attention to avoid damage to sprinkler heads.
- Flooring: Do not drag heavy object across carpets/flooring use appropriate moving equipment and/or carry all objects.
- Flooring: As part of the acoustic treatment to the apartments, some areas of tiled and timber floors are laid
 over an acoustic underlay. As the underlay is flexible, a protective layer of soft fabric and stiff load
 distribution sheeting (i.e. plywood) should be used when moving heavy furniture and whitegoods over tiles.
 This will prevent potential damage to the tiles and grout joints.

1.2 For your action: service connections

You are responsible for ensuring that service accounts are connected in your name upon occupation of your new home.

The following contact details of common service providers have been listed for your convenience. The list does not include all potential services.

Refer to Section 4: apartment services for detailed information regarding services.

Service	Company	Contact Details
Electricity – Connection	OC Energy	1300 49 40 80
Electricity – Embedded Network	OC Energy	1300 49 40 80
Gas	OC Energy	1300 49 40 80
Water - Cold	Yarra Valley Water	1300 651 511
Water - Hot	OC Energy	1300 49 40 80

1.3 For your information

Australia Post

The building has been registered with Australia Post for delivery of mail. If you require mail to be diverted from your existing address to your new home apply for mail re-direction (a form can be obtained at any Australia Post branch).

Postal Address for the building is: 20 Hepburn Road, Doncaster, Victoria, 3108

Water

Service	Provider	Contact number
Water	Yarra Valley Water	1300 651 511

Contact Yarra Valley Water upon handover of your apartment to arrange connection of your water services.

Waste collection

Service	Provider	Contact number	
Waste collection	Waste Wise Environmental	Jacob Rossignuolo	
		0407 028 207	

The Building Manager is responsible for overseeing the waste management contractor. The Waste Management program has been put in place following the endorsement of the Waste Management Plan approved by Manningham City Council. The Building Manager will provide information regarding waste disposal and collection.

Insurance

The Owners Corporation is responsible for insuring the common property building and common property contents. Each owner and/or occupant is responsible for insuring their apartment (including home and contents/contents). We recommend each owner and/or occupants seek advice from a professional insurance broker.

2 Being in an Owners Corporation

2.1 Strata title

Magnolia is a strata titled building. As an owner of an apartment, you are the owner of a lot within a strata scheme.

All areas within the building which do not form part of an individual apartment lot are common property, such as the entry lobby, lifts, car park, building structure and services. The common property is owned by the **Owners Corporation**, and all owners contribute financially to the maintenance of these areas.

The Owners Corporation is the body which represents all the apartment owners collectively. As an apartment owner, you are automatically part of the Owners Corporation and are responsible for how the building is managed and for financial contributions to maintenance of the common property.

2.2 Owners Corporation

The Owners Corporation deals with all matters associated with the management and administration of the common property including:

- maintenance, cleaning and repairs;
- Insurances (such as building, public liability, workers compensation etc.);
- control, cleaning and use of the common facilities;
- matters relating to garbage, noise, pets and the like;
- administration and sinking fund;
- by-laws; and
- Administration of the Executive Committee.

The Executive Committee is a body of volunteer owners who are elected to represent the Owners Corporation in the day to day running of the strata scheme.

2.3 Strata Managing Agent

The Owners Corporation has appointed **Cura Community Management** as manager of the Owners Corporation.

The Strata Managing Agent's responsibilities include:

organisation of repairs and maintenance of common property;

- arranging of quotations for services/works;
- engagement of caretaker, cleaners, gardeners, tradespeople;
- convening, recording and attendance at Annual General meetings;
- maintaining all accounting records, bank accounts, collecting levy contributions, issuing levy notices, etc.;
- routine inward and outward correspondence;
- insurance renewal, valuations and lodgement of claims;
- maintenance of the Owners Corporation Register, supervision of the common seal;
- preparation of Owners Corporation certificates;
- generally implementing the decision and instructions of the Owners Corporation; and
- Providing guidance to the Owners Corporation in performance of its duties and functions.

The Strata Managing Agent is appointed by the Owners Corporation at their general meetings.

2.4 Levies: administration and sinking fund

Levies are the financial contributions paid by all owners to the Owners Corporation to cover the running costs incurred in the management of the building and for allocation for capital expenditure. Each owner pays a share of the cost which is apportioned according to the unit liabilities (ULs), outlined in the Plan of Subdivision.

At each Annual General Meeting a budget is set for the anticipated expenditure for the year. Levies are then determined and resolved for the administrative and sinking funds.

2.5 Strata by-laws

Strata by-laws are a set of "rules" that the owners and tenants in a strata scheme must follow. They set out the rights and obligations of all parties involved within the building and have been created to ensure a cohesive living environment. They can be amended, and new by-laws can be introduced, by the Owners Corporation.

A copy of the Owners Corporation by Laws are included. They cover topics such as moving goods and furniture, keeping of pets, cleaning, concierge/security, parking etc.

2.6 Modifications to your apartment

Prior to any building work being undertaken in your apartment, you may need to obtain the required consents from local council, Owners Corporation and any other relevant authority.

Refer to your by-laws included in your Owners Pack for relevant clauses relating to Owners Corporation Consent, including Behaviour of Owners, Occupiers and Permitted Persons, Common Property, External Appearance, Floor Coverings, Building Works and Alterations (Consents, Notice to Owners Corporation, Carrying out of Building Works and Alterations).

Consistent with the by-laws, the following is a summary of the procedures which must be followed:

- 1. Contact the Owners Corporation and local council to confirm required approvals;
- 2. Ensure proposed modifications are consistent with by laws and any relevant codes;
- Submit details of proposed modifications to Owners Corporation for approval prior to undertaking any work.
 Include description of works, estimate of time for undertaking works, and all necessary supporting documentation and other approvals; and
- 4. During the works:
 - protect, keep clean and make good all common property; and
 - ensure consideration of all residents works are not to produce excessive noise, work hours are to be
 as imposed by local council, use of lifts is to be reasonable, dust to be kept to a minimum, rubbish is to
 be disposed of, etc.

2.7 Acoustic and fire separation between apartments

Considerable care has been taken to ensure that floors, ceilings and walls to all apartments have been designed to achieve a high standard of acoustic and fire separation between dwellings.

Any proposed modifications to these surfaces, such as a change to the floor finish from carpet to tiles, installation of down lights in the ceiling, installation of entertainment/sound system components (i.e. plasma screens, speakers etc.) or the hanging of artwork, must:

- be designed to maintain the existing standard of acoustic and fire separation; and
- Be installed by an experienced tradesperson.

W

Poor workmanship, inadequate acoustic provisions or any unacceptable noise transference may lead to the work being reversed and reinstated at the owner's expense.

Please note:

 Floor mounted speakers must be acoustically isolated when positioned on hard surfaces such as timber floor or tiles.

- Wall mounted speakers for sound systems or plasma TVs must be installed on appropriate acoustic isolation brackets.
- Chasing for electrical work on walls between apartments will generally not be acceptable.

2.8 Safety: cleaning and maintenance protocol

Please assist the Building Manager in its role by reporting any common property cleaning or maintenance needs when noted.

As the owner of an apartment, you are responsible for the cleaning and maintenance of your apartment and all areas within your lot, including your balcony, courtyard, terrace, car park and storage area, if relevant.

The Owner's Manual, aims to provide a helpful guide on the cleaning and maintenance of your apartment.



However, where appropriate, the use of professional cleaners and licensed tradespeople with necessary safety equipment is recommended.

For your safety, and that of other residents:

- consult this manual and the by-laws, prior to undertaking maintenance and cleaning works;
- untrained or unlicensed persons should not attempt to service or alter electrical, communications, gas, water or plumbing fixtures or services;
- children must always be supervised (particularly on balcony or external areas);
- do not stand on a chair to clean, service or repair any item use an approved for purpose ladder;
- do not stand on a raised platform, chair or ladder of any height on balconies or adjacent to windows or stairwells; and
- Do not lean out of windows or over balconies to clean, service or repair any item.

Any activity that requires external work, or the use of ladders, must be carried out in accordance with all relevant legislation, codes and guidelines.

3 Common facilities

3.1 Resident entry and security


The main pedestrian entry is off Hepburn Road.

The building is electronically secure, which means residents are required to use their proximity card to gain access throughout the building. The proximity card will provide access at the following points:

- Main pedestrian entry foyer;
- Pedestrian Access via stairwell adjacent the substation on Short Street
- Level 12 common area
- Level 14 common area

Along with the proximity card, residents are required to use their standard apartment entry door key to gain access to their apartments. The following keys are included in your Owner's Pack

- 1. 2x Access Fobs
- 2. 2x Mail box keys
- 3. 2x Apartment Entry Keys
- 4. 1x Remote Control
- 5. 2x Balcony Door Keys



In the event of power failure, residents will be able to enter the building and take the fire stairs to their apartment level. The proximity card system & intercom will not work.

The following are step by step instructions for gaining entry:

Main Foyer Entry: Present proximity card to proximity reader. The reader is a long black plastic switch approximately 100mm long mounted below the Video intercom in the case of the main entry, and it can recognise a card within 100mm. Once the card is recognised, a short beep will sound and the entry door will unlock. Card readers are located outside of the main foyer entry, in the Foyer Entry Airlock, at the stair landing door off Short Street, at the L12 common area entry door, and at the L14 common area entry door.

3.2 Visitor access

To maintain security throughout the building, visitor access can only be authorised by a host resident, via the audio intercom system.



Please ensure that visitors are identified PRIOR to providing access to the building.

The following are step by step instructions for granting entry to visitors:

- 6. **Identify Visitor:** The visitor must press the host's apartment number into the video intercom, located adjacent to the lobby doors and press the Bell Key. This calls the video handset within the host's apartment. The host resident must simply press the talk button on their handset to communicate back to the entry intercom point.
- 7. **Authorise Entry:** To grant access, the host must press the button with the key symbol on their handset to open the main entry door.
- 8. **Exit:** Authorisation is not required for visitors to exit the building using the main entry.

See the detailed operational instructions on the security system included in the handover manual.

3.3 Mail



An individually keyed mail box is provided for each apartment – the mail room is located within the Foyer Entry. Keys for the mailbox are included in your Owners Pack.

3.4 Garbage and recycling

Each floor is serviced by one rubbish chute. These are located in the common areas by the lift/stairs on each floor. Please ensure that any waste deposited into the rubbish chutes is appropriately bagged. Do not deposit loose rubbish, especially cardboard or anything else that could block the chute. Recycling bins are provided by the Body Corporate within the waste rooms on each level.

3.5 Fire procedures and safety



The Owners Corporation is responsible for maintaining an Emergency Management Plan and ensuring all residents are adequately advised of fire safety procedures.

In summary:

- ensure you are familiar with Emergency Management Plan(s) and evacuation procedures established by the Owners Corporation;
- note the nearest fire exit to your apartment; and
- fire doors must remain closed at all times;

The Owners Corporation is responsible for the repair, maintenance and annual fire certificate of all building fire services, such as fire doors (including your apartment entry door), fire stairs, sprinklers, audible warning system, fire extinguishers, fire hose reels, common area smoke detectors, manual call points, emergency lighting etc.

The Owners Corporation or Building Manager will arrange access to each apartment, if necessary, for the annual inspections of these services.



Please note that your apartment door is fitted with smoke seals and contributes to the fire protection system for the building. If you wish to install new or additional locks or door hardware, you must notify and obtain permission from the Owners Corporation in writing and ensure a qualified locksmith undertakes the work to install the correct hardware.



Each owner is responsible for maintaining the smoke detectors within their apartment. *This detector is not connected to the fire brigade. (Refer to Section 4: Apartment Services - Smoke Detectors).*

Please note that smoke detectors in the common areas are linked to the Melbourne Fire Brigade (MFB). Cooking smoke should not be dispersed into the common hallways as this will activate attendance by the MFB; expensive fines apply for false alarms. Any contractors engaged should also be aware that sanding equipment and heat equipment may also activate attendance by the MFB. You should seek advice from the Owners Corporation or Building Manager.

4 Apartment services

Utilities

4.1 Electrical service

Your apartment has a normal domestic 240 volt, single phase power supply, for its own use.

OC Energy has been contracted to establish and maintain and embedded electricity network for the property, a detailed fact sheet on how to connect electricity to the apartment is contained in the handover kit. The electrical meter is located in the electrical meter/services cupboard near the lift on you floor, not within your apartment. You do not pay for the power used by other apartments.

Your apartment's electrical switchboard is located inside your apartment. All light, power, air conditioning, range hood, oven, dishwasher and exhaust fans circuits are protected by circuit breakers at the switchboard. For added personal protection, power points (GPOs) (including those into which appliances are plugged) and lighting circuits have a safety switch.



Should your safety switch trip for any reason, follow these steps:

- 9. Isolate/turn off all GPOs and lights, and unplug all appliances.
- 10. Reset the safety switch.
- 11. If the safety switch cannot be reset, contact a licensed electrician as a fault exists with either the wiring or the switch itself.
- 12. Turn on the GPOs one at a time or until the safety switch trips. When it trips, you have found the faulty outlet.
- 13. Plug your appliances back into GPOs one at a time or until the safety switch trips. When it trips, you have determined the cause of the fault. Talk the faulty appliance to a qualified service centre for repairs.



For safety reasons, ensure an adequate air space is left around the apartment switchboard. Do not store items in front of or in contact with the switchboard.



Please note that a licensed electrician must be engaged to locate and fix any fault with the power supply or the switchboard.

4.2 Gas service

Your apartment has a separate gas supply for its private use.

In the event of an emergency, the Gas isolation valve is inside the kitchen cupboards or behind draws, adjacent to the cook top.

Billing for the gas usage for the cook tops in all apartments will be billed through the body corporate management.

Please note that a licensed plumber must be engaged to locate and fix any fault with the gas supply.

4.3 Water service

Cold Water is provided by Yarra Valley Water. For connection, contact Yarra Valley Water on 1300 651 511

To turn off the water supply to your apartment, use the stop cock located in water meter services cupboard next to the stairwell/lift on your floor. Contact your Building Manager for access to this cupboard.

W

A licensed plumber must be engaged to locate and fix any fault with the water supply, or fix or replace any fitting such as a tap or showerhead.

4.4 Hot water

Hot water is supplied from a central gas hot water heating system and is maintained by the Owners Corporation. OC Energy will bill each unit for individual hot water usage. For connection, contact OC Energy on 1300 49 40 80

4.5 Air conditioning

Your apartment is supplied with an air-cooled, reverse cycle, split air conditioning system for heating and cooling your home. In all instances, your air conditioning condenser unit is located within the apartment courtyard/balcony.



The air conditioning system can be operated in a variety of ways, to suit your preferences. To take full advantage of the air conditioning system and to ensure correct maintenance, refer to the Operating Instructions for the Control Panel, included in your Owners Pack and appendices.

The control unit allows you to control the temperature and operation of the system, including timer. The following tips will assist in optimising the performance of your air conditioning:

- To achieve an even temperature throughout the apartment, run all air conditioning units at the same time and set at the same temperature.
- Generally, a temperature range between 20°C to 25°C is considered comfortable.
- The system can be set to either "cool" or "heat" or it can be set to automatically switch from heating to cooling to maintain a consistent temperature via the "Auto On" or "Auto" setting.
- Controls can also be configured to circulate air at all times or be turned off when there is no demand for heating or cooling.
- Extreme settings such as 15°C or 28°C do not improve the systems performance or increase the rate of heating or cooling. They are likely to lead to uncomfortable conditions in a short space of time.
- To maximise air flow and the efficiency of the system, leave all internal doors open.
- Do not leave your apartment closed up for more than four hours with a minimum temperature selected on the thermostat. This may cause freezing of condensate drains and cause water damage.

Owners are responsible for the maintenance of their own air conditioning system, including the air conditioning condenser. Please note that the 12 month warranty provided is conditional on maintenance being undertaken during the warranty period, including routine maintenance, cleaning the air filter and checking various items annually. Refer to the Resident's Instructions, Warranty and Warranty Checklist included in your Owners Pack.

Communications

4.6 Telephone and fax

Your apartment has been provided with a telephone/fax connection point.

These points are suitable for connecting your telephone(s), fax machine(s) and/or ADSL, and are interchangeable (i.e. they can be used for either/or telephone or fax).

4.7 Telephone lines

Your apartment has been wired for telephone lines. You will need to contact NBN co. to arrange your telephone account and the details of your service. A licensed electrician must be engaged if additional telephone lines are required.

4.8 Free to air TV

A community master antenna is located on the roof of the building and is tuned to receive a quality signal for free-to-air commercial television. The signal is reticulated throughout the building to each apartment.

Ш

The TV reception outlets in the walls are "screw in" (F Type) connections and may not fit your existing television lead. "Conversion" (F type to pal) fly leads are required to connect your TV or video to the outlets. Free to air can be obtained from either of the two outlets on the wall.

As the frequency of the signal may vary slightly from your previous antenna system, your television may need to be re-tuned to ensure an optimum quality reception. We recommend you engage the services of an experienced technician to assist you in re-tuning your TV if necessary.

Free to Air channels 2, 7, 9 and 10 should be tuned via VHF. SBS and Channel 31 should be tuned via UHF. Digital MATV signal has been provided for Freeview channels.

4.9 Pay TV (cable)

Pay TV cable, suitable for Pay TV (FOXTEL), has been supplied wired into your apartment ready for final connection by the provider.

You will need to contact the Building Manager to arrange connection of Pay TV to your apartment. A connection fee is applicable.

Apartment security and fire safety

4.10 Intercom

An intercom video unit is located within the apartment. This unit has a control button to allow visitor access to the building.



Please refer to the Intercom Instructions included in your Owners Pack.

4.11 Smoke detection

Your apartment is provided with one or more 24 volt DC main powered (via the Fire Information Panel) smoke detector unit with a backup battery, generally fixed to the ceiling outside the bedroom(s). An alarm is sounded from a detector when smoke is present, to alert occupants.



Note: You must remove the yellow protective cover when you move into the apartment.



The detector is connected to the Fire Information Panel (FIP) within the building. If the smoke alarm is tampered with or removed, the FIP will be alerted and a technician will be automatically called. The smoke alarm, upon detection of smoke will emit an alarm to alert all occupants. Due to the design of the fire detection system within the building, it is a requirement that these alarms are connected to the FIP (as detailed above) and are also not fitted with "silent", or "hush" buttons. If the alarm sounds due to smoke from cooking activities etc., it will continue for 30 seconds, when, if no further smoke is detected, it will become silent. If smoke is still present, it will continue to sound the alarm. In order to disperse any smoke and silence the alarm, open all external windows and doors to dissipate the smoke (do not open the door to the public corridor/hallway as this may result in the fire brigade to be called). As always when cooking, it is recommended that the range hood is in operation to extract any unwanted smoke or fumes. If the smoke alarm detects any thermal disturbances such as flames, the Fire Brigade will be automatically alerted and thus, the MFB will attend the premises immediately.

4.12 Door and window security

Apartment entry doors are lockable. Balcony sliding doors are lockable internally.




Keys for your door are included in your Owners Pack.

5 General maintenance

5.1 Finishes schedule and sub-contractor and suppliers list

A detailed Finishes Schedule and a list of the major Sub Contractor and Suppliers are included as Appendix B and C of this manual.

5.2 Appliances



- Cooktop;
- Oven;
- Dishwasher;
- Range hood;
- Intercom; and
- Air Conditioner.

To maintain the appearance and durability of your appliances, follow the instructions, hints and advice in these documents.

W

Please note that the Manufacturers' Warranties are often conditional, and require regular maintenance. We also recommend appliances be inspected every two (2) years by an authorised service agent.



Ensure you mail your product registration cards to the appliance manufacturer.

In the event an appliance malfunction, follow these steps:

- 14. Check power at the switchboard;
- 15. Follow relevant instructions in the Operation Manual; and/or
- 16. Check the warranty and call the manufacturer's service centre.

5.3 Paint



Refer to Appendix C: Finishes Schedule for paint specification, including colour. As paint colour may change subtly over time, and paint manufacturers may alter colour specifications, we recommend any future colour matching be based on a paint sample.

Most marks can be removed with a clean damp cloth. Use a diluted sugar soap mix if necessary. Avoid excessive 'scrubbing' and the use of scourers of any type, as this may alter the finish of the surface.

5.4 Timber Flooring

The timber flooring to your apartment has been selected to provide a rich, high quality feel. Regular maintenance will result in prolonged life of your flooring. Manufacturer's recommendations are included within your handover pack but are summarised below:

- Sweep or vacuum as often as necessary to remove any loose dirt or grit.
- Use protective mats at all exterior entrances. Do not use rubber-based mats as the rubber may leach into the flooring.
- Use felt protectors under heavy pieces of furniture. Never slide or roll furniture or appliances across your floor. Protect the surface if using a trolley to move heavy objects.
- Spiked heels or shoes in need of repair can severely damage your floor.
- In areas of excessive traffic and wear, make use of runners or area rugs.
- Damp mop only avoid excessive amounts of water. Steam mops must not be used. If a spill occurs, soak up the bulk liquid promptly. Never use oil, soap, wax or other household products to clean your floor.
- Keep animal nails trimmed.
- Maintain relative humidity levels between 30% and 70%.

5.5 Lighting

LED Lights have been fitted to the apartment. LED lights offer long service life and high energy efficiency, even though initial costs are higher than those of fluorescent and incandescent lights.

5.6 Aluminium doors and windows

Aluminium windows and doors have a powder coat finish, which needs to be cleaned and maintained regularly to ensure the decorative and protective properties of the coating are retained.

Cleaning is recommended every three to six months to remove air born deposits such as salt, atmospheric pollution and dirt.

To clean:

- remove dust with a wet sponge (rather than risk micro scratching by dry dusting);
- remove any marks by the use of a warm, mild detergent or mineral turpentine;
- wash and remove powder deposits from the powder coating surface using a soft bristle brush; and
- Always rinse afterwards with fresh water so that the contact time with the cleaning solution is kept to a minimum.

Do not use abrasive cleaners; harsh solvents (including window cleaner or industrial strength solvents or solvents recommended for the removal of sealant or mastic), scouring pads or other harsh materials such as powder based cleaning products as these may scratch the finish. Always test a small discrete section of a frame to confirm the suitability of the cleaning agent used. This will ensure minimal or no damage to the powder coat colour or surface.



Window furnishings are not to be mounted on any part of the aluminium door or window frame.

5.7 Door and window hardware

To maintain a high level of function, door hardware must be free from dust and grit. Generally, all components can be cleaned with a soft damp cloth. Grease or oil should not be applied to any hardware.

Maintain door locks and handles every 6-12 months, as necessary:

- tighten fixing screws;
- re-align strike plates;
- lubricate internal mechanism with a suitable lubricant; and
- Lubricate "sticky" locks with dry powder graphite sprinkled on the key.

5.8 Glass windows and balustrades, shower screens, splashbacks and vanity mirrors

To clean glass and mirrors, use clean water with mild soap, diluted methylated spirits, glass cleaner or a slightly acidic (vinegar) cleaning solution on a soft, lint free, damp cloth or chamois. Always apply the cleaner onto the cloth first and not directly onto the glass.

To avoid scratching, do not use caustic or abrasive substances such as polish, silicon based cleaners' powder-based cleaning agents and other harsh materials, and do not use cleaning items such as steel wool, scouring pads or razor blades. If using a solvent cleaner, care should be taken to avoid contact with the glazing sealant and any other materials which may be affected by the solvent. Avoid using a broom and hose to clean windows as this can result in scratched glass and leaking windows.

Please note that the external face of windows and glass balustrades should be cleaned by a professional cleaner with the required safety equipment.

Damaged glass and mirrors cannot be repaired. They must be replaced by an experienced glazier.

5.9 Tapware

To prevent damage to the protective finish, avoid cleaning taps and spouts with harsh chemicals. Clean with warm soapy water, rinse well and dry with a soft cloth.

To maintain tapware:

- clean tap filters every two months; and
- Check tap washers every two years, and replace as necessary.

A licensed plumber is required to replace the ceramic washer in lever mixer taps.

Remember to turn off the water supply to your apartment prior to carrying out maintenance or in the event of a tap or fitting breaking.

5.10 Reconstituted Stone bench tops

The Reconstituted stone featured in your apartment has been selected for its appealing finish, warm character, durability and high quality.

Reconstituted Stone bench tops

- Use a chopping board, place mats and coasters to protect the surface from scratching, dulling or heat marks.
- Avoid sitting or standing on the bench tops.
- Wipe up spills immediately, to avoid potential absorption of substances into stone.
- Pay particular attention to substances such as soap, detergents, abrasive or harsh chemicals or cleaners, solvents, toothpaste, tea, coffee, alcohol, vinegar and citrus juices as these may stain, etch or dull the stone.
 Lipstick, industrial and laundry marker and ink are unlikely to be removable. Avoid resting steel or items which may rust on the stone, to prevent rust markings.
- Do not use acids, wax, sealers, steam cleaners or petroleum products on stone.

Avoid getting chemicals, such as paint removers, wine, oven cleaners, etc., on the Stone bench top countertop. If a spill does occur, promptly flush the surface with water to fully rinse off the chemical.

5.11 Tiles floor, walls – porcelain or vitrified

To clean, use a mix of warm water with a biodegradable detergent and a cup of methylated spirits. When dry, buff with a dry mop or woollen cloth.

5.12 Stainless steel kitchen sink, laundry tub, trims etc.

To clean, wipe with a soft damp slightly soapy cloth, let dry and wipe with a dry cloth. Always wash and wipe with the grain of the stainless steel, to avoid scratching.

To protect from staining after cleaning with a chemical cleaner or coming into contact with food acid, wash down with fresh water.

To brighten, use a non-abrasive cleaner or specialist stainless steel product.

Do not use steel wool, abrasive cleaner, or oil based cleaners.

5.13 Cupboard joinery

To clean and maintain, follow these guidelines:

- remove soiled particles from surfaces or light stains with warm soapy water and a soft cloth, or a nonabrasive spray and wipe cleaning agent;
- do not use abrasive or alkaline cleaners and ensure that the finish does not remain in contact with hypochlorite bleach, mineral acid, dye or iodine solution, silicon based cleaners, polish, steel wool, acidic and alkaline materials. (Note that silicon cleaners render surfaces unsuitable for recoating.);
- ensure all spills are cleaned up immediately with a damp cloth and dry off, to prevent swelling or damage;
- buff out minor fine scratches (note the gloss level will diminish);
- check, tighten and adjust hinges every six months; and
- Do not apply oil or grease to any joinery hardware, such as hinges, runners etc.

5.14 Sanitary-ware acrylics, porcelains

To preserve the polish surface of your pan(s) and basin(s), clean with a soft cloth and warm soapy water or a liquid cleaner to wash away any oils or soap residue. Ensure any selected cleaning agent does not affect any adjacent stone or tile.

Do not use powders, pastes, crème cleaners, thinners, window cleaning sprays or dry cleaning fluids etc. Stubborn marks or fine scratches may be polished out with Brasso.

5.15 Ceiling exhaust ventilation grill

The exhaust grill in the bathroom and laundry will assist the removal of steam and humid conditions, prolonging the life of the interior finishes. The removable ceiling diffuser should be cleaned every 4 months with a soapy cloth and dried prior to replacement. Do not alter the position of the exhaust vents when cleaning.

A single fan operates to the bathroom, ensuite and laundry. This can be switched on or off from the fan switch in the laundry or via the light switch in each bathroom. Ensure that if you are using the fan in the laundry, that you do not switch off the fan when entering/leaving the bathroom.

The fans are generally very quiet and may not be heard when they are operating in each room. This is not a problem, and can be easily checked by going into the main bathroom where the access hatch, and fan motor is located and listening for the fan motor noise.



Leaving a window within your apartment slightly open will increase the air intake and efficiency of all the internal exhaust mechanisms (including kitchen range hood), and will aid to minimise any naturally occurring condensation.



To ensure adequate air flow into the laundry exhaust, leave the laundry door open while the dryer is in use.

5.16 Laundry floor waste

To ensure the water seal in the laundry floor waste does not dry out and let odours escape, each fortnight a small amount of water is required to go into the laundry floor waste. Use a container and pour approx 600mls of water into the floor waste.

5.17 External Paver

To ensure good drainage and prevent a build-up of dirt or dampness around outdoor pot plants, all pots should be raised slightly off the tile surface. Very large, heavy pots should also be avoided, to prevent excessive loads on the building structure.

6 Environmentally Friendly Tips

According to the Department of Climate Change and Energy Efficiency Households produce almost one-fifth of Australia's greenhouse gas emissions. The conservation of environmental biodiversity is also directly related to how we live, interact and consume resources.

Our lifestyles and the management of our households have a direct impact on production of greenhouse gases and the future of the environment.

The following are simple things that can be done in the home to conserve resources, reduce greenhouse gas emissions and save money on energy and water bills.

6.1 Living rooms

- Minimise heat loss through windows by installing window coverings, such as blinds with pelmets.
- Do not overheat or overcool set the thermostat at a practical level.
- Switch televisions, DVD Players (etc.) off when not in use these appliances use substantial amounts of energy even when left in the 'standby' mode.
- Switch off the VDU screen to your computer when not in use. Laptop computers are generally more efficient than desktops.

6.2 Lighting

- Turn off lights when not in use.
- Use lamps where a light source is most needed.

6.3 Kitchen

- Use energy efficient cooking practices where possible. Minimise grilling and use lids on pots when boiling and simmering etc.
- Use a plugged sink to rinse dishes and clean vegetables.
- Wait until you have a full load to run the wash cycle on your dishwasher.
- Ensure that refrigerator door seal is tight fitting and maintained. Leave the door open for as little time as possible.

6.4 Bathroom

- Do not leave the tap running when brushing teeth or shaving.
- Choose the toilet's half flush option as much as possible.
- Do not leave taps dripping and promptly repair leaking taps.
- Place a little food dye in the cistern of your toilet from time to time and check for small continuous leaks down the back of the pan.

6.5 Laundry

- Use cold water for machine washing.
- Wait until you have a full load to run the wash cycle on your washing machine.
- Use biodegradable soap.
- Use drying racks instead of the clothes dryer. If a clothes dryer is used, run on a lower and colder setting.

6.6 Waste

- Separate your waste into recyclable collections.
- Buy less packaging.
- Don't put oils, fats or harmful chemicals down the sinks.
- Use a strainer in kitchen sinks.
- Choose detergents with no, or little, phosphorous, to minimise nutrient loads in waterways.

6.7 Green Travel

The site is well positioned in terms of access to public transport, with numerous services available in the vicinity of the site.

The bus services in the area all provide good access to numerous metropolitan bus routes, which in turn provide connections to greater Melbourne. Information on public transport fares, routes and timetables is available at the following website:

http://ptv.vic.gov.au/

Appendix A: Copy of the by-laws

Appendix B: Sub contractor/Services Contacts List

The following list of sub-contractors and suppliers has been provided for your future reference and convenience. Please note, Hamilton Marino Builders is not responsible, and cannot warrant, any future work undertaken by these trades as a result of your direct negotiations or instructions.

Sub Contract	Company	Contact Details
Appliances (Standard – Asko)	Asko	1300 002 756
Appliances (Upgrade – Miele)	Miele	1300 464 353
Plumber	BP Plumbing	03 9560 6119
Electrical	GFS Electrical	03 8786 3742
National Broadband Network	NBN Co	1800 687 626
Electricity Embedded Network	OC Energy	1300 494 080
Air Conditioning	Coldflow	03 8572 1250
Fire Sprinklers	SRD Fire Protection	03 5941 5678
Roofing	Burelli Roofing	03 9338 5115
Carpentry	Urban One Construction	0434 210 502
Carpet	Omnifloor	03 9687 6688
Joinery	Moorabbin Cabinets	03 9555 7571
Tiler & Water-Proofer	Tile Effect	03 9551 3850
Kitchen Bench Tops	Tile Effect	03 9551 3850
Storage Cages	JLM Fencing	03 9768 2501
Screens, Robes & Mirrors	Precision Shower Screens	03 9728 8100
Painter (External)	McKinnon Painting	03 9333 3066
Painter (Internal)	McKinnon Painting	03 9333 3066
Plasterer	Oneway Constructions	03 8774 2506
Lift	Kone	03 9934 8029
Door Hardware	Lavco Industries	03 9338 2092
Bathroom Fixtures	Harvey Norman	03 8530 6399
Bathroom Accessories	Harvey Norman	03 8530 6399

Appendix C: Finishes schedule/Supplier List

Paint: Apartments	
Walls (Warm Scheme)	Dulux Low Sheen – Natural White
Walls (Light Scheme	Dulux Low Sheen – Natural White
Ceilings (Light and Warm Schemes)	Dulux Flat – Natural White
Woodwork (Light and Warm Schemes)	Dulux Gloss – Natural White
Entry Door Frames Internal Apartment	Dulux Gloss – Natural White
Entry Door Frames Corridors	Dulux Gloss – Black
External Walls/Slab Edges	Taubmans Low Sheen – Whitsunday Island
Balcony Soffits	Taubmans Texture – Whitsunday Island
Slab Edges	Taubmans Kow Sheen – Whitsunday Island
Paint: Communal areas	
Service doors and frames	Dulux Gloss – Natural White
Stair doors and frames	Dulux Gloss - Black
Walls	Dulux Low Sheen - Natural White
Ceilings	Dulux Flat - Natural White

Carpet/Timber Flooring				
Supplier	Design	Colour		
Victoria Carpets	VCC Tudot Twist 32OZ (Light Scheme)	Turret		
Victoria Carpets	VCC Tudot Twist 32OZ	Maiden		
Timber Flooring	Pacific Flooring	Santa Monica Beach House		

Tiles, Pavers and Benchtops

Supplier	Product	Format	Surface	Product Description
Tile Effect	Bahtroom/Laundry Floor	-	600x300	Matt Grey
Tile Effect	Bathroom/Laundry Wall	-	600x30	Gloss White
Tile Effect	Kitchen Benchtop	-		White/Grey
Tile Effect	Balcony Paver	-	600x300	Bluestone

Joinery Apartments

Kitchens Cabinets (Warm/Light Scheme)
Kitchen Cabinets Overhead (Warm Upgrade)

Kitchen Cabinets (Warm Standard)

Robe Internals

Bathrooms (Standard)

Bathrooms (Upgrade)

White Gloss 2PAC Timber Veneer

Timber Look Laminate White Melamine

Timber Look Laminate

Timber Veneer

Appendix D: Attachments

- Condensation in apartment's information sheet
- Security System operational instructions
- Smoke Alarm Manual
- Intercom Operational Instructions
- A/C operational instructions
- Range hood user Manual
- Oven User Manual
- Dishwasher User Manual
- Cooktop User Manual
- Fridge User Manual
- Timber Flooring maintenance information
- NBN connection information
- Benchtop User Manual
- Paint maintenance information
- Carpet Care
- Waste Chute training and operation manual
- OC Energy Welcome Pack



20-24 Hepburn Road, Doncaster Victoria, Australia 3108

magnolia don caster hill.com. au

